Multi-Use USB TEMP&RH Data Logger User Manual LCD SCREEN-START/SCROLL/MARK LED LIGHT-STOP BUTTON MRAIA -USB INTERFACE

The device is mainly used to monitor the temperature and humidity of food, medicine, chemical products and other products during storage and transportation. It is widely

Product Introduction

used in all links of warehousing and cold chain logistics, such as reefer containers, refrigerated trucks, refrigerated distribution boxes, cold storage laboratory, etc. Compact. light and economical to use. After the recording is completed, inserting it into the USB port of PC or computer. it will automatically generate reports without any driver.

Product Features

- > Designed to be multi-use > Temperature & Humidity measurement and recording > Wide measuring range, high accuracy and large data
- memory

- > Statistics available on LCD screen No software needed to export data > Automatically generates PDF report and CSV file > Programmable software for logging parameters, alarms. and start delay

±3%RH; ±0.5°C(-20°C ~ +40°C), ±1.0°C(other) Accuracy Operating Range Humidity 0% ~ 100%RH, Temp -30℃ ~ 60℃ 0.1RH%: 0.1°C/T Resolution Memory Capacity 32.000 Recording Options Push-To-Start or Start Delay

Parameter

Technical Parameter

Temperature Scale To or T

Interval Programmable (10s~18h) [Default: 10 mins] Start Delay Programmable (0~254 mins) [Default: 30 mins] Alarm Delay Programmable (0~960 mins) [Default: 10 mins] Programmable high or low alarm limit for each Alarm Range channel [Default: <2°C or >8°C, <40%RH or >80%RH] Typically 1 Year: CR2032 3.0V Lithium Battery Shelf Life / Battery (Depending on sampling rate and environment) Report Generation Simultaneously generate PDF report and CSV file Communication USB 2.0 Interface

a. Start Recording Press and hold the ">" button for more than 3s until the "OK" light is on, and the ">" or "WAIT" displays on the

Operating Instruction

- screen, indicating starting recording successfully.
- b. Mark When the device is recording, press and hold the "▶" button for more than 3s, and the screen will switch to the "MARK" interface. The number of "MARK" will increase by
- one, indicating data was marked successfully. (Note: One record interval only can mark one time, the logger can mark 6 times in one recording trip. Under status of start delay, the mark operation is disabled.)
- c. Stop Recording Press and hold the "■" button for more than 3s until the "ALARM" light is on, and the "" displays on the screen,
- WAIT START DELAY LOG -LOG MARK __TEMPERATURE SCALE DATA VALUE-RH%—HUMIDITY SCALE During normal recording process, shortly press "▶" to switch to different display interface. The interfaces shown
- 464 ①Real-time Temperature Interface @Real-time Humidity Interface

a. If the device is used for the first time or after

the initialization interface.

every 10s.

re-configuration, the real-time temperature interface will be

b. Real-time temperature and humidity interface is updated





- ®Real-time Temperature Interface
 - (4) Real-time Humidity Interface

- UTC +0:00 (Default) Time Zone Dimension 89mm*36mm*16mm Product Weight 25g

without data.)

- indicating stopping recording successfully. (Note: If the logger is stopped during the status of start delay, a PDF report generated when inserted into PC but
 - Limit Interface → Humidity Upper Limit Interface → Humidity Lower Limit Interface.

in sequence are respectively:

LCD Display Instruction

ALARM STATUS

UPPER/LOWER LIMITS

Real-time Temperature Interface → Real-time Humidity

Interface → LOG Interface → MARK Interface →

- Temperature Upper Limit Interface → Temperature Lower
- (Above Upper Limit)
- VA & A & Z A AWARH (Below Lower Limit)

6,82,85

(Initialization)

A A A RH

At the real time temperature / humidity interface: If the symbol ">" lights, indicating the data logger is recording: If the symbol "=" lights, indicating the data logger has stopped recording: If the "WAIT" lights, indicating the data logger is in the status of start delay: If the symbol "x" and "1" light, indicating the measured humidity are within the normal range; If the symbol "x" and "1" light, indicating the measured temperature/humidity exceed is temperature/humidity upper limit; If the symbol "x" and "1" light, indicating the measured temperature/humidity exceeds its temperature/humidity	©Temperature: Above Upper Limit (Stop recording status) ©Temperature: Below Lower Limit (Stop recording status)	Status	Button Indicator light Press and hold the "" The "OK" (green light) will light for 3s. After turning on, press and hold the "" button for 3s. Battery Status Indication Battery Status Indication Indicator light Status Status Start Recording Start under turning Start Recording Start under Status Indication Battery Status Indication Capacity	Step 1 Step 2 Step 3 Step 4	Step1: Turn the battery cover anticlockwise to open it. Step2: The battery cover position is as shown, indicating that it has been rotated to the accordant position. Step3: Take off the battery cover. Step4: Remove the CR2032 battery. Step5: Replace the battery. (Please note that the positive and negative anodes) Step6: Please install the battery cover as the direction shown. Step7: Cover the battery and clockwise rotate it to close. Step8: The battery cover is oriented as shown, indicating that the battery cover is installed tightly.
lower limit. Log MARK MARK SLOG Interface (Stop recording status)	©Humidity: Above Upper Interface (Stop recording status) @Humidity: Below Lower Limit (Stop recording status)	Note: As long as over limit is found during the recording process, the "Of" light will no longer flash. Not press the button The "Off." (green light) and "Alarm" (red light) don't flash. The "Off." (green light) flashes, indicating there is not over limit during the recording process. The "Alarm" (red light) flashes, indicating it is over limit during the recording process.	ME 40% – 100% IE 15% – 40% IS 5% – 15% IC < 5% Note: When the battery power is lower than 5%, please replace the CR2032 battery with a new one.	Step 5 Step 6 Step 7 Step 8	Note: It is recommended to check the battery status before restarting the logger to ensure that the remaining battery capacity could finish the recording task. When the logger is connected to computer under the status of recording or pause status, it is prohibited to plug out the logger without battery power supply.